


Blow Off Backdraft



Existing Tables

The reason for the Blow Off Backdraft (BOB) when most people get done sanding a product they blow off the product. Thus sending the dust to another location of the plant. Migrating dust is one of OSHA's largest dust fines. Denray has designed a system that mounts to their Existing dust tables, with the purchase of a new top that will have the holes laid out as in drawings below. You may use your existing rails or purchase new rails, BOB units can be ordered for the backs or either of the ends. Unless ordered to be one full piece the new top will be made as a split top, Due to extreme truck freight, both the split tops and the BOB unit can be shipped Via UPS small package. Check the QR code below for more info on the split top.

When ordering new tables with the BOB system it will come with tops as pictured below. When ordering The BOB systems for existing table a new top must also be ordered at the same time.



End BOB systems are referred to as End width and either R for right or L for left. Ex. 48L pictured to the right.

- 2800 with BOB 48
- 2872 with BOB 72
- 2896 with BOB 96
- 3648 with BOB 48
- 3672 with BOB 72
- 3672 with BOB 36R or 36L
- 3696 with BOB 96
- 3696 with BOB 36R or 36L
- 4800 with BOB 48
- 4800 with BOB 48R or 48L
- 4872 with BOB 72
- 4872 With BOB 48R or 48L
- 4896 with BOB 96
- 4896 with BOB 48R or 48L



Watch How to Assemble a Split Top



Blow-off Backdraft for New Machines



Scan to Visit Denray's Online Document Library